



CARE & CLEANING INSTRUCTIONS



1 Rinse all surfaces with lukewarm water to remove dust and debris.

! IMPORTANT ! TO PREVENT SCRATCHING, BLOT, DO NOT WIPE.

2 Using a microfiber cloth, gently blot with mild soap and lukewarm water.

! IMPORTANT ! RINSE CLOTH IN CLEAN WATER FREQUENTLY.

3 Rinse thoroughly with clean, lukewarm water.

4 Blot dry with a clean microfiber cloth.



ONLY USE THE FOLLOWING TO DISINFECT YOUR ACRYLIC DIVIDER - pharmacy grade hydrogen peroxide, isopropyl alcohol diluted with water to 30 percent strength, or household bleach and water (50:1). Other products can damage your screen. Apply with soft clean cloth.



Infection Control

If there is a need for infection control, bleach can be used in accordance with CDC Cleaning and Disinfection instructions. The solution ratio should be 5 tablespoons of bleach to 1 Gallon of water or 4 teaspoons of bleach per quart of water. Spray apply the solution as a mist and then wipe off the surface moisture to help spread the bleach solution

Always try these methods in an inconspicuous place on the product prior to trying on a visible area.

Barriers – Manufacturer Recommended Cleaning Methods

SAFCO®

ACRYLIC

Clean as needed with non-abrasive acrylic cleaner (such as Brilliantize® or Novus® No. 1) or mild dish soap and a clean, lint-free, microfiber cloth.

Avoid using: ammonia, abrasives, and aromatics and all-purpose cleaners. Acrylic is prone to scratching; never wipe acrylic with a dry cloth, or brush over it with a bare, dry hand.

1. Remove all the dust and dirt; either blow the debris off the polycarbonate or use water and a soft cloth to float off the debris. Making direct, dry contact with surface particles using your hand or a cloth can actually grind them into the material itself, causing scratches to the surface.
2. Spray nonabrasive acrylic cleaner, onto a one- or two-foot-square section of the acrylic. (For an on-hand alternative, a solution of mild dish soap and water works well too.)
3. Once the cleaner has been applied, use a soft, lint-free microfiber cloth to gently wipe the surface down, again being careful to make contact only with the portion of the surface that already has cleaner on it. Continue applying the cleaner and wiping it off in small sections until you've finished the entire surface.

Polycarbonate Whiteboard Surfaces

Use a non-abrasive cloth and non-abrasive soap solution similar to a liquid dish soap or castile soap. Wipe with clean water and let air dry.

MasterVision®

No restrictions – use mild or harsh, abrasive chemicals alike.



Whiteboard Surface

1. Wipe the board free of dry erase
2. Use a cleaning solution (recommend a board cleaner for general use or non-abrasive disinfectant if needed)
3. Dry surface with a dry cloth or towel. **IMPORTANT!** Ensure there is no cleaning residue that remains on the surface as this can impact board performance.



COATED TEXTILE: POLYURETHANE UPHOLSTERY

COATED TEXTILES

POLYURETHANE COATED UPHOLSTERY

Contourett Only

- For wet spills gently blot with dry cloth to remove spill
- For dried spill gently work the spill in a non-aggressive circular motion using a damp cloth making sure to not oversaturate the fabric.
- For dried stains use a mixture of Tide® or Oxiclean® and warm water (1 teaspoon of soap for every 16 ounces water) - follow instructions for dried spills above. Make sure to wipe away any excess soap left behind and remove any moisture with a dry cloth.
- For non-liquid spills always remove excess contaminant from surface before cleaning. The use of a soft brush or soft abrasive can be used to remove dried contaminants before performing liquid cleaning.
- For Healthcare related stains a water to bleach solution of 5:1 is recommended. Rinse cleaned area with water.
- For stains requiring the use of a solvent, spray the solvent directly onto the stain and allow it to sit for 2-3 minutes, avoid over saturating the fabric - follow directions for dried stains above.
- Always allow fabric to air dry.

Approved cleaners for Contourett:

It is important to remember that after use of any cleaning agent, the fabric should be rinsed with water and wiped dry to remove any remaining residue or moisture. Shockwave, Recon, Benefect, Microban, Greased Lightning-Degreaser, Lysol Wipes, Diluted bleach solution (5:1 water to bleach), Dispatch disinfectant towels with bleach, PDI Sani-Hands wipes, PDI Super Sani-Cloth germicidal disposable wipes, Diversity Morning Mist Neutral Disinfectant Cleaner, Virex 256, Fantastik, Oxycide, Formula 409.